


» JOY EC 3AO

Electronic Fancoil Thermostat
(from Version 2.0.0)

thermokon[®]
HOME OF SENSOR TECHNOLOGY

Datasheet

Subject to technical alteration
Issue date: 24.04.2019 • A101



» APPLICATION

Modern design, flush mounting fan coil room thermostat. Used for individual control of temperature in commercial, industrial and residential buildings. It is tailored for two-pipe and four-pipe fan coil units with two-wire electric valves or controlling a 6-way valve (Sauter or Belimo). The device combines a modern design with a 2,5" LCD and a touch-sensitive surface, 3 time program options each with 4 time periods options.

» SECURITY ADVICE – CAUTION



The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

» NOTES ON DISPOSAL



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

» REMARKS TO ROOM SENSORS

Location and Accuracy of Room Sensors

The room sensor should be mounted in a suitable location for measuring accurate room temperature. The accuracy of the temperature measurement also depends directly on the temperature dynamics of the wall. It is important, that the back plate is completely flush to the wall so that the circulation of air occurs through the vents in the cover. Otherwise, deviations in temperature measurement will occur due to uncontrolled air circulation. Also the temperature sensor should not be covered by furniture or similar devices. Mounting next to doors (due to draught) or windows (due to colder outside wall) should be avoided.

The temperature dynamics of the wall will influence the temperature measurement. Various wall types (brick, concrete, dividing and hollow brickwork) all have different behaviours with regards to thermal variations.

Surface and Flush Mounting

The temperature dynamics of the wall influence the measurement result of the sensor. Various wall types (brick, concrete, dividing and hollow brickwork) have different behaviours with regard to thermal variations. A solid concrete wall responds to thermal fluctuations within a room in a much slower way than a light-weight structure wall. Room temperature sensors installed in flush boxes have a longer response time to thermal variations. In extreme cases they detect the radiant heat of the wall even if the air temperature in the room is lower for example. The quicker the dynamics of the wall (temperature acceptance of the wall) or the longer the selected inquiry interval of the temperature sensor is the smaller the deviations limited in time are.

» TECHNICAL DATA

Measuring values	temperature	
Output voltage	3x 0..10 V, max. load 5 mA, EC Fan control, heating & cooling or control 6-way valves (configurable via Software)	
Power supply	24 V = ($\pm 10\%$) or 24 V ~ ($\pm 10\%$) SELV	
Power consumption	max. 1,5 W (24 V =)	
Measuring range temp.	0..+50 °C	
Accuracy temperature	± 1 K (typ. at 21 °C)	
Inputs	DI 1 1 input for NTC10K or floating contact	DI 2 DI 3 2 digital inputs for floating contacts
Control function	setpoint adjustment 0..+50 °C	
Display	LCD 2,5", 240x160 px, white backlighting	
Functions	integrated PI-controller	
Enclosure	PC, hardened acrylic glass with high scratch resistance	
Protection	IP30 according to EN 60529	
Connection electrical	Terminal 1..8 terminal block max. 1,5 mm ²	Terminal 9..12 terminal block max. 1.0 mm ²
Ambient condition	0..+50 °C, max. 85% rH non-condensing	
Weight	195 g	
Mounting	flush mounted with standard EU box ($\varnothing=60$ mm)	

» PRODUCT TESTING AND CERTIFICATION



Declaration of conformity

The declaration of conformity of the products can be found on our website <https://www.thermokon.de/>.


» DIAGNOSTICS MENU

To access the diagnostics menu, select the header in the startscreen of the parameter menu, and press the ENTER key. Here you will find various information, such as device type, software version, state of the inputs and outputs and controller state (current manipulated variable).

» MOUNTING ADVICES

Plasterboard boxes shall be covered by wall paper or paint to avoid that the plasterboard box's front rim will be partially visible underneath JOY. Maybe consider using white plasterboard boxes (i.e. Kaiser 9063-77)


» CONNECTION PLAN



1 Digital Input 2	12 GND DI 3
2 EC Fan (0..10 V)	11 Digital Input 3
3 Cooling (0..10 V) or 6-way valve	10 GND DI 1
4 Heating (0..10 V) or 6-way valve	9 Digital Input 1 (or NTC10K)
5 GND DI 2	
6 GND	
7 24 V = (±10%) or 24 V ~ (±10%)	
8 GND	

» FUNCTION DESCRIPTION – BUTTONS

On the touch surface, there are adjustment options for setpoint and fan speed regulation.



With power-button (E), the device can be set in standby mode by pressing the button (if keycard-switch function is NOT used). If the button is used as a occupancy button, the button must be pressed for at least 3s, in all other cases, a short actuation is sufficient. In standby mode, the display and all outputs are switched off (controller deactivated). The frost and heat protection monitoring remains active.

» FUNCTION DESCRIPTION – CONTROLLER/FAN STAGES

The room thermostat has a "PI controller" for heating and cooling.

6WV (PI-controller 0..10 V)

The usage of a 6-way valve is set via the configuration software. In this case the same manipulated variable is output at terminals 3 and 4.

The manipulated variable is output as a proportional control signal at the output for the 6-way valve. The type of valve used is set via the configuration software.

You can choose from 2..10 V / 2..10 V INV (Belimo), 0..10 V DN15 / DN15 INV, DN20 / DN20 INV (Sauter).

Fan stages

In automatic mode the fan speed is linked to the controller. The assignment of the fan stage to the control (heating / cooling, only heating, only cooling) is freely selectable. To ensure that the fan motor starts reliably, a period of time can be configured in which the fan starts with maximal value. Using one or more time channels, the fan control have to be set per timechannel and per period. Via the touch surface the user has the option to override the settings of the device every time. When the next time channel starts, the fan speed is set to the configured value. The fan is set to automatic mode when the user changes the occupancy state (occupied↔unoccupied).

EC Fan automatic mode

The 0..10 V (0..100%) control of the fan is proportional to the calculated manipulated variable of the PI controller.

Example:

Calculated actuating variable 65% → Fan control with 6,5 V.

Calculated actuating variable 22% → Fan control with 2,2 V.

EC Fan manual

Up to 5 steps (steps) can be set using the configuration software. The set number of steps is divided linearly to the manipulated variable of 0..100%.

Example:

Max. steps (stages) = 5

Stage 1 = 20%

Stage 2 = 40%

Stage 3 = 60%

Stage 4 = 80%

Stage 5 = 100%

Max. steps (stages) = 3

Stage 1 = 33%

Stage 2 = 66%

Stage 3 = 100%

Heating/ cooling with PI-controller (0..10 V)

The time response of the PI control loop depends on the control parameters x_p for the proportional area and t_n for the reset time of the integral range. In case of an error variable, the P portion immediately changes the position value proportionally to the error variable, while the integral portion takes effect after a certain time.

The resulting manipulated variable is output as an analogue 0..10 V signal directly to the outputs.

Proportional range X_p

The proportional band is the deviation in which controller emits 100% value. A small X_p leads to a stronger control action in case of slight deviations, but increases the oscillation tendency.

Integral time T_n

The reset time T_n is the time which the I-component of the controller would require to produce the same positioning signal that the P-component forms immediately once the control deviation is present. The effect of the I component decreases with increasing reset time.

Minimum and maximum actuating variable


This setting defines a fixed minimum or maximum value of the actuating variable. The parameter "Mode selection actuating variable" can be used to select whether the minimum actuating variable a) is retained until the controller changes its mode or b) whether the actuating variable of the controller is output to the output only when the minimum actuating variable is exceeded.

Parameter	Value (default)*
Base set point	21 °C
Hysteresis	± 0,5 °C
Number Fan stages	3
Start-up period	1 s
PWM cycle time	30 Min
Dead band Heating/Cooling	2,0 °C
Dead band Heating/Cooling ECO-mode	10 °C
Min. set point	0,0 °C
Max. set point	50 °C
Standby set point decrease (unoccupied)	-2,0 °C
Frost protection	7,0 °C
Heat protection	35 °C
Step width	0,5 °C
Set point adjustment	± 3 °C

*changes on request

Main screen/ Value display

The Display shows the measured value of the internal sensor. The value of an external sensor will be shown if connected and configured accordingly. The room thermostat controls in this case according to the external sensor.



Header

Current date and time will be displayed in the header. If enabled, ECO-mode status is indicated via symbol .

Footer


Depending upon the heating or cooling mode, occupancy or window contact status, the corresponding symbols will be shown in the footer. The symbol “active timechannel” will be shown only if active.

Symbols

Occupancy		
Window contact/dewpoint		
Heating/Cooling		
Fan Speed		
Active timechannel		

» CONFIGURATION MENU

Buttons



The configuration menu is activated by simultaneously pressing the buttons “up” (A), “left” (D) and “right” (B) for at least 3 seconds.

Menu
Timechannels ▶
Inputs ▶
Time/Date ▶
Sensor settings ▶
Common settings ▶

Menu navigation on the touch-surface is performed by pressing the buttons “up” (A), “down” (C), “left” (D), “right” (B) or the power button. Choose the desired parameter and press “right” (B) to open up the submenu. The menu will default after 30 seconds if no button is pressed. To exit the menu select the header line and press “left” (D).

» MENU → TIME CHANNELS

Set point and timer can be set in this menu. Three different time channels with four periods of time are available. The Time channels are prioritised. Channel 3 has the highest priority.

Timechannels	Timechannels/Timer1	Timechannels/Periods	Periods/Period1
Timechannel 1 ▶	Week Mo-Su	1: 06:00h - A - 22.0° ▶	Start <-/+> 06:00h
Timechannel 2 ▶	Working week Mo-Fr ✓	2: 08:30h - 1 - 20.0° ▶	Fan <-/+> AUTO
Timechannel 3 ▶	from day <-/+> Mo	3: 16:00h - A - 22.0° ▶	Temp <-/+> 22.0°
	to day <-/+> Fr	4: 22:30h - 0 - 22.0° ECO ▶	ECO-Mode ✓
	Periods ▶	<- Reset	


Choose the time channel and press “right” to enter the submenu. It is possible to select the total week as well as individual days

The selected parameter will be marked with the symbol ✓

To edit the parameter of the selected timer, select “Periods” and press “right”.

ECO-mode is also available in the menu “section”, when selecting the dead zone increase from 2 °C to 10 °C. The adjustable dead zone between the activation of heating or cooling modes enables an optimisation between comfort and energy saving.

The dead zone between heating and cooling in the ECO-mode will be set to the configured deadband range (see common settings). (default 10.0 K)



» MENU → INPUTS

Up to 3 inputs are configurable for functions such as windows contact, dew point, occupancy, change-over or external sensor option.

Sensor (NTC10K)

The value of an external sensor will be shown if connected and configured accordingly. In this case, the room thermostat controls according to the external sensor.

Change-Over DI

Which controller is active depends on the state of the Change-Over contact. (Factory default: contact open heating controller active, contact closed cooling controller active). The terminals 3 and 4 are used as outputs for heating resp. cooling.

Change-Over Sensor

The Change-Over Sensor is used for switching between heating and cooling mode automatically. If the temperature is below 19 ° C, the controller is in cooling mode. If it is above 28 ° C, it is a heating mode.

If an input is configured as a change-over, the room thermostat is automatically in 2-pipe operating mode and both outputs (terminals 3 and 4) are used as outputs for heating resp. cooling.

Window contact/Energy hold off

If a window contact is enabled via the digital input, the reference will switch to a setback set point (Heat SP/Cool SP).

Dewpoint

An active dewpoint contact locks the cooling controller.

Occupancy

If occupancy-function is active, the symbol will be displayed automatically. In state of "unoccupied" the heating set point is reduced by 2K (default setting) resp. the cooling set point raised by 2K.

Keycard-Switch


When the card is not inserted, the device is switched in sleep mode. Operation of the keys is locked, the display is switched off and the controller adjusts to the nominal values of the "unoccupied"-State.

Overview of possible combinations

Input 3 (Clamp 1 and 5)	Input 2 (Clamp 11 and 12)	Input 1 (Clamp 9 and 10)
Change-Over DI Dewpoint sensor Windows contact	Window contact	Sensor
		Window contact
		Dewpoint sensor
		Occupancy sensor
		Keycard switch
	Dewpoint sensor	Sensor
		Window contact
		Dewpoint sensor
		Occupancy sensor
		Keycard switch
	Occupancy sensor	Window contact
		Dewpoint sensor
		Keycard switch
	Keycard switch	Sensor
		Window contact
		Dewpoint sensor
		Occupancy sensor
Occupancy sensor	Window contact	Sensor
		Window contact
		Dewpoint sensor
		Occupancy sensor
	Dewpoint sensor	Sensor
		Window contact
		Dewpoint sensor
	Keycard Switch	Occupancy sensor
		Sensor
Not used	Change-Over DI	Window contact
		Dewpoint sensor
		Occupancy sensor
		Keycard switch
		Sensor
	Window contact	Window contact
		Change-Over DI
		Change-Over Sensor
		Window contact
		Dewpoint sensor
		Occupancy sensor
		Keycard switch
	Dewpoint sensor	Sensor
		Change-Over DI
		Change-Over Sensor
		Window contact
		Dewpoint sensor
		Occupancy sensor
		Keycard switch
	Occupancy sensor	Sensor
		Change-Over DI
		Change-Over Sensor
		Window contact
		Dewpoint sensor
	Keycard switch	Keycard switch
		Sensor
		Change-Over DI
		Change-Over Sensor
		Window contact
		Dewpoint sensor

» MENU → TIME/DATE

Time, Date and display format can be configured in the menu settings. The room thermostat is equipped with a real-time clock so that it automatically adjusts for daylight-saving time. This function can be disabled in the datetime settings.



» MENU → SENSOR SETTINGS

Available with temperature offset correction of the integrated temperature value.

The temperature display can also be changed from °C to °F.


Sensor settings		
Offset int.	◀-/▶	0.6 K
Value int.		22.1°C
Offset ext.	◀-/▶	0.2 K
Value ext.		22.1°C
Unit	◀-/▶	Celsius

» MENU → COMMON SETTINGS

The common settings includes the brightness of the background lighting and the LED.

Valve protection, prevents the valves becoming ceased when they are switched off for long periods.

If the valve protection function is activated, a valve-check is carried out every Friday at 11:00 am for the heating valve and 11:15 am for the cooling valve. The corresponding valve is triggered for 5 minutes, if not activated the last 96 hours. The deadzone can be adjusted (default 10.0 K, see timechannels). The room thermostat has 3 outputs for fan control with up to 3 fan stages. The amount of fan stages are configurable.



Factory settings

By selecting "Factory setting", the room thermostat will be reset and restore the device to factory default settings.

» ANWENDERHINWEISE

Bootloader

Im Gerät ist ein Bootloader integriert, der es ermöglicht eine neue Applikation (Update, Upgrade) mittels SD-Karte einzuspielen. Um eine SD-Karte einzustecken, muss das Oberteil abgenommen werden! Ist der Bootloader aktiv, blinkt die Ring-Beleuchtung im 1s-Takt. Das Display wird nicht angesteuert! Nach Erkennung einer SD-Karte mit gültiger Applikation wird der Update-Vorgang gestartet. Die Ring-Beleuchtung blinkt nun im 300ms-Takt. Nach erfolgreichem Beenden des Updatevorgangs (Dauer ca. 2-3 Minuten!) startet automatisch die neue Applikation. Die SD-Karte muss anschließend entfernt werden!

SD-Karte

Die MicroSD-Karte kann zusätzlich dazu verwendet werden, um eine Konfiguration aus dem JOY auszulesen. Dabei kann die MicroSD-Karte während der laufenden Konfiguration eingesteckt sein oder nach Abschluss der Konfiguration eingesetzt werden. Ist während der Konfiguration eine Micro-SD-Karte eingesteckt, wird jeder Lern-/Auslern-Vorgang direkt in die Datei eingetragen. Wird die MicroSD-Karte erst nach der Konfiguration eingesteckt wird die Konfigurationsdatei nach Neustart automatisch auf der Karte erstellt.


Only MicroSD cards formatted in the FAT file system can be used! NTFS and exFAT file systems are not supported.

Software

Eine ausführliche Anleitung zur Parametrierung und die dazugehörige Konfigurationssoftware des Raumthermostats JOY finden Sie zum Download in unserem Downloadcenter.

The parameters for the display, set point, controller and the 6-way valve output configuration can only be changed via the configuration software.

» DIMENSIONS (MM)



» ZUBEHÖR (OPTIONAL)

Zierrahmen reinweiß für JOY
MicroSD-Karte 2GB

Art.-Nr.: 614771
Art.-Nr.: 500098